```
2 Imports System.Ling.Expressions
3 Imports System.Net.Http.Headers
4 Imports System.Runtime.CompilerServices
   ''' <summary>
5
6
   ''' </summary>
7
8
9
   Partial Public Class measureTask
10
       Public mParam As MeasureParameter
11
       Public cParam As ControlParameter
12
       Public Sub New(ByVal tasktype As String)
13
           mParam.TaskType = tasktype
14
15
           InitMparam()
       End Sub
16
       Private Sub InitMparam()
17
18
           mParam.Arraytype = 0
           mParam.NoAdChUse = 10
19
20
           mParam.MaxV = 2
21
           mParam.MaxI = 2
22
           mParam.lpMode = 0
           mParam.MaxVval = maxVvals(mParam.MaxV)
23
24
           mParam.MaxIval = maxIvals(mParam.MaxI)
25
26
           Select Case mParam.TaskType
               Case "DC" ' Or "dc" Or "Dc" Or "dC"
27
28
                    mParam.CycleLen = 4
29
                    mParam.CycleLenVal = cyclelenvalsDC(mParam.CycleLen)
30
                    'mParam.maxN = 10
               Case "IP" ' Or "ip" Or "Ip" Or "iP"
31
32
                    mParam.CycleLen = 0
33
                    mParam.CycleLenVal = cyclelenvalsIP(mParam.CycleLen)
34
                    ResetlPparam()
35
               Case "SP" 'Or "sp" Or "Sp" Or "sP"
36
                    mParam.CycleLen = 0
37
                    mParam.CycleLenVal = cyclelenvalsSP(mParam.CycleLen)
           End Select
38
39
           mParam.MaxN = 10
40
           mParam.Elspacing = 5.0
41
           mParam.NoStack = 1
42
           mParam.ErrorLimit = 5.0
            'mParam.OnOff = False
43
44
           mParam.Interval = interval
45
           mParam.EstTime = 0
46
           mParam.ElInc = 1
47
           ResetOnOffTime()
48
49
       End Sub
50
       Public Sub ResetIPparam()
51
           mParam.Vdly = ipParam(mParam.CycleLen, mParam.lpMode, 0)
52
           mParam.Mdly = ipParam(mParam.CycleLen, mParam.lpMode, 1)
53
           ReDim mParam. Tw(19)
54
           For i As Integer = 0 To 19
55
               mParam.Tw(i) = ipParam(mParam.CycleLen, mParam.lpMode, i + 2)
56
           Next
```

```
57
        End Sub
 58
        Public Sub ResetOnOffTime()
             If mParam.TaskType = "DC" Then
 59
 60
                mParam.OnTime = dcOntime(mParam.CycleLen)
 61
                mParam.OffTime = dcOfftime(mParam.CycleLen)
            Elself mParam.TaskType = "IP" Then
 62
                mParam.OnTime = ipOntime(mParam.CycleLen)
 63
 64
                mParam.OffTime = ipOfftime(mParam.CycleLen)
 65
            End If
 66
        End Sub
 67
        Public Sub EstimateTime()
 68
            mParam.EstTime = mParam.CycleLenVal * mParam.NoCmd * mParam.NoStack * >
              EsttimeMult
 69
        End Sub
 70
        Public Sub ResetControlParameter()
 71
             cParam.TaskType = mParam.TaskType
             cParam.JSONDir = mParam.JSONDir
 72
 73
             cParam.DataDir = mParam.DataDir
 74
             cParam.FileNameBase = mParam.FileNameBase
             cParam.MaxN = mParam.MaxN
 75
 76
             cParam.CycleLenval = mParam.CycleLenVal
 77
             cParam.MaxVval = mParam.MaxVval
 78
             cParam.MaxIval = mParam.MaxIval
             cParam.OnTime = mParam.OnTime
 79
 80
             cParam.OffTime = mParam.OffTime
 81
             cParam.Vdly = mParam.Vdly
             cParam.NoStack = mParam.NoStack
 82
 83
             cParam.NoCmd = mParam.NoCmd
             cParam.Cmds = mParam.Cmds
 84
 85
             cParam.NoAdChUse = mParam.NoAdChUse
             cParam.Arraytype = mParam.Arraytype
 86
 87
             cParam.ElStart = mParam.ElStart
             cParam.ElEnd = mParam.ElEnd
 88
             cParam.Ellnc = mParam.Ellnc
 89
 90
             cParam.Elspacing = mParam.Elspacing
 91
 92
        End Sub
        Public Sub ResetStartDate()
 93
 94
             If DateDiff(DateInterval.Minute, mParam.StartDate, mParam.EndDate) > 0 >
 95
                mParam.StartDate = mParam.StartDate.AddMinutes(timeSpan)
 96
            End If
 97
         'Public Sub SetFileNameBase()
 98
99
             mParam.FileNameBase = (mParam.TaskType & mParam.JST.ToString("yy/MM/ >
          dd HH:mm"))
100
101
        Public Sub SetFileNameBase(ByVal str As String)
102
             mParam.FileNameBase = str
103
104
        Public Sub SetJST(ByVal _d As Date)
             'Debug.WriteLine(_d.ToString("yy/MM/dd HH:mm"))
105
106
             mParam.JST = d
107
108
        Public Sub CopyDirStructure(ByVal _json As String, ByVal _datadir As
          String)
```

```
109
            mParam.JSONDir = _json
110
            mParam.DataDir = _datadir
111
        End Sub
        112
           MakeCmdSP
113
        114
        Public Sub MakeCmdSP(ByRef rNo(,) As Integer, ByRef eNo(,) As Integer,
115
          ByVal sbNo As Integer)
            Dim relay() As Integer
116
117
            Dim relay2() As Integer
118
            Dim nEl As Integer = 0
119
            ' check number of electrodes
120
121
            For i As Integer = 0 To sbNo - 1
122
                If rNo(i, 0) > 0 Then
123
                    nEI = nEI + Math.Abs(rNo(i, 0) - rNo(i, 1)) + 1
124
125
                If rNo(i, 2) > 0 Then
                    nEI = nEI + Math.Abs(rNo(i, 2) - rNo(i, 3)) + 1
126
127
                End If
128
            Next
129
            ' make relay number vector
130
            ReDim relay(nEI - 1)
131
132
            Dim indx As Integer = 0
            Dim ellnc As Integer
133
            For i As Integer = 0 To sbNo - 1
134
135
                If rNo(i, 0) > 0 Then
                    ellnc = 1
136
137
                    If rNo(i, 0) > rNo(i, 1) Then
138
                        ellnc = -1
139
140
                    For j As Integer = rNo(i, 0) To rNo(i, 1) Step ellnc
141
                        relay(indx) = i
142
                        indx += 1
                    Next
143
                End If
144
                If rNo(i, 2) > 0 Then
145
146
                    ellnc = 1
147
                    If rNo(i, 2) > rNo(i, 3) Then
148
                        ellnc = -1
149
                    End If
                    For j As Integer = rNo(i, 2) To rNo(i, 3) Step ellnc
150
151
                        relay(indx) = j
152
                        indx += 1
153
                    Next
154
                End If
155
            Next
156
157
            ' extract relay numbers to use measurement
158
            indx = 0
            nEl = Int((mParam.ElEnd - mParam.ElStart) / mParam.ElInc) + 1
159
            ReDim relay2(nEl - 1)
160
            For i As Integer = mParam.ElStart To mParam.ElEnd Step mParam.ElInc
161
162
                relay2(indx) = relay(i - 1)
163
                indx += 1
```

```
164
            Next
165
166
167
              make cmd
168
            Dim ncmd1 As Integer = Clnt((nEl - 1) / mParam.MaxN)
169
            ReDim mParam.Cmd1(ncmd1, mParam.MaxN + 2)
170
171
            ReDim mParam.NoCh(ncmd1)
172
173
            For i As Integer = 0 To ncmd1
174
                mParam.Cmd1(i, 0) = 0 'Tx electrode as 0
                mParam.Cmd1(i, 1) = 0
175
176
                Dim chcnt As Integer = 0
177
178
179
                Dim ind1 As Integer = i * mParam.MaxN
                Dim ind2 As Integer = Math.Min((i + 1) * (mParam.MaxN), nEl - 1)
180
181
                For j As Integer = ind1 To ind2
                    mParam.Cmd1(i, j - ind1 + 2) = relay2(j)
182
183
                    chcnt += 1
184
185
                mParam.NoCh(i) = chcnt - 1
186
            Next
187
188
            Dim ncmd As Integer = 0
            For i As Integer = 0 To ncmd1
189
                ncmd += Math.Ceiling(mParam.NoCh(i) / mParam.NoAdChUse)
190
191
            Next
192
193
            ReDim mParam.Cmds(ncmd - 1, mParam.NoAdChUse + 2)
            'Dim indxC As Integer = 0
194
195
            Dim indxP As Integer = 0
196
            Dim indxR As Integer = 0
            mParam.NoCmd = 0
197
198
            For i As Integer = 0 To ncmd1
                For j As Integer = 0 To Math.Ceiling(mParam.NoCh(i) /
199
                  mParam.NoAdChUse) - 1
                    '====== debug ========
200
                    'System.Console.WriteLine(mParam.nCh(i))
201
202
                    mParam.Cmds(indxR, 0) = mParam.Cmd1(i, 0)
203
                    mParam.Cmds(indxR, 1) = mParam.Cmd1(i, 1)
204
                    For k As Integer = indxP + 2 To Math.Min(mParam.NoAdChUse +
205
                      indxP + 2, mParam.NoCh(i) + 2)
206
                        mParam.Cmds(indxR, k - indxP) = mParam.Cmd1(i, k)
207
208
                    mParam.NoCmd += 1
209
                    indxP += mParam.NoAdChUse
210
                    indxR += 1
211
                    If indxP >= mParam.NoCh(i) Then
212
                        indxP = 0
213
                    End If
214
                Next
215
            Next
        End Sub
216
217
         '-----
```

```
218
           MakeCmd
         219
        Public Sub MakeCmd(ByRef rNo(,) As Integer, ByRef eNo(,) As Integer, ByVal →
220
           sbNo As Integer)
221
            Dim relay() As Integer
222
            Dim relay2() As Integer
223
            Dim nEl As Integer = 0
224
225
             ' check number of electrodes
226
            For i As Integer = 0 To sbNo - 1
227
                 If rNo(i, 0) > 0 Then
228
                    nEI = nEI + Math.Abs(rNo(i, 0) - rNo(i, 1)) + 1
229
                End If
230
                 If rNo(i, 2) > 0 Then
231
                    nEI = nEI + Math.Abs(rNo(i, 2) - rNo(i, 3)) + 1
232
                End If
233
            Next
234
235
             ' make relay number vector
            ReDim relay(nEl - 1)
236
237
            Dim indx As Integer = 0
238
            Dim ellnc As Integer
239
            For i As Integer = 0 To sbNo - 1
                 If rNo(i, 0) > 0 Then
240
241
                     ellnc = 1
242
                     If rNo(i, 0) > rNo(i, 1) Then
243
                         ellnc = -1
244
                     For j As Integer = rNo(i, 0) To rNo(i, 1) Step ellnc
245
246
                         relay(indx) = j
                         indx += 1
247
248
                     Next
249
                End If
                 If rNo(i, 2) > 0 Then
250
251
                     ellnc = 1
252
                     If rNo(i, 2) > rNo(i, 3) Then
                         ellnc = -1
253
                     End If
254
                     For j As Integer = rNo(i, 2) To rNo(i, 3) Step ellnc
255
256
                         relay(indx) = j
257
                         indx += 1
258
                     Next
259
                End If
260
            Next
261
262
             ' extract relay numbers to use measurement
263
             indx = 0
            nEl = Int((mParam.ElEnd - mParam.ElStart) / mParam.ElInc) + 1
264
265
            ReDim relay2(nEl - 1)
266
            For i As Integer = mParam.ElStart To mParam.ElEnd Step mParam.ElInc
267
                 relay2(indx) = relay(i - 1)
268
                 indx += 1
269
            Next
270
271
            Select Case mParam.Arraytype
                Case 0 ' dipole dipole
272
```

```
273
274
                    ReDim mParam.Cmd1(nEl - 4, mParam.MaxN + 2)
275
                    ReDim mParam.NoCh(nEl - 4)
276
277
                    For i As Integer = 0 To nEl - 4
278
                          System.Console.WriteLine(i)
                        mParam.Cmd1(i, 0) = relay2(i)
279
280
                        mParam.Cmd1(i, 1) = relay2(i + 1)
281
                        Dim chcnt As Integer = 0
282
                        For j As Integer = i + 2 To Math.Min(i + mParam.MaxN + 2, >
                        nEI - 1) '(i+12, nEI - 1) <- this gives error
283
                            mParam.Cmd1(i, j - i) = relay2(j)
284
                            chcnt += 1
285
                        Next
286
                        mParam.NoCh(i) = chcnt - 1
287
                    Next
288
289
                    Dim ncmd As Integer = 0
290
                    For i As Integer = 0 To nEl - 4
291
                        ncmd += Math.Ceiling(mParam.NoCh(i) / mParam.NoAdChUse)
292
293
                    '====== debug ========
294
                     'System.Console.WriteLine("ncmd{0}", ncmd)
295
296
                    ReDim mParam.Cmds(ncmd - 1, mParam.NoAdChUse + 2)
297
                     'Dim indxC As Integer = 0
298
299
                    Dim indxP As Integer = 0
                    Dim indxR As Integer = 0
300
301
                    mParam.NoCmd = 0
                    For i As Integer = 0 To nEl - 4
302
                        For j As Integer = 0 To Math.Ceiling(mParam.NoCh(i) /
303
                        mParam.NoAdChUse) - 1
                             '====== debug =========
304
305
                             'System.Console.WriteLine(mParam.nCh(i))
                            mParam.Cmds(indxR, 0) = mParam.Cmd1(i, 0)
306
                            mParam.Cmds(indxR, 1) = mParam.Cmd1(i, 1)
307
308
309
                            For k As Integer = indxP + 2 To Math.Min
                        (mParam.NoAdChUse + indxP + 2, mParam.NoCh(i) + 2)
                                 mParam.Cmds(indxR, k - indxP) = mParam.Cmd1(i, k)
310
311
                            Next
                            mParam.NoCmd += 1
312
313
                             indxP += mParam.NoAdChUse
314
                             indxR += 1
315
                             If indxP >= mParam.NoCh(i) Then
316
                                 indxP = 0
317
                            End If
318
                        Next
319
                    Next
320
                     '====== debug ========
                     'System.Console.WriteLine("mParam.ncmd{0}", mParam.nCmd)
321
322
323
                Case 1 ' pole pole
324
325
                Case 2 ' modified pole pole
```

```
E:\Git\gdam\cRho_v1.0\cls_measureTask.vb
```

```
326
327
                Case 3 ' Wenner
328
329
                Case 4 'schlumberger
330
331
                Case 5 'modified pole pole
332
333
            End Select
334
335
336
        End Sub
337 End Class
338
339
```